



**FILTER HOUSING  
SIDESTREAM INSTALLATION**

**Filter Housing inlet connects to  
discharge side of circulation pump.**

**Filter Housing outlet connects to  
suction side of circulation pump.**